



DSC Alarm Quick Reference Sheet

<u>Function</u>	<u>Keys to Press</u>	<u>Results</u>
Check for open zones	Hit # key	Shows open zone numbers
Arm entire system	Hold down “away” button	Arms system in 45 sec. Red light illuminates
Arm perimeter only	Hold down “stay” button	Bypass motion detector No delay on windows
Disarm System	Input master or user code	System beeps & green ready light illuminates
Bypass Zones	*1,zone number to be bypassed (ei. 01,02, etc), #	Does not arm zone entered. Bypassed for one setting.
Chime Mode	Press Chime button	Use to turn on and off
**System Test	*6, master code, 4, #	Siren will sound then test all contacts
Change Master Code	*5, current master code, 40, new 4 digit code, #	Confirmation beeps New master code input
Add User Codes	*5, master code, positions 01-32, then new code	Confirmation beeps Adds another user code
Set System Time/Date	*6,mstr,1,HH/MM (military time), mo/day/yr, #	Takes a few minutes to display new time
Check For Trouble	*2	Displays numbers @ top of screen—see user manual for instructions.
Check Alarm Memory	*3	Shows zones opened in memory

For Service: TechHomeConnect 720-891-0060
Monitoring Station: (303) 825-8195 or (800) 441-3662
Recommended to test system once a month